

**Tools and  
Materials  
Needed for  
Assembly**



Drill



Hammer  
and Mallet



Wood Glue  
(optional)



Bar Clamp



Cutter



Pencil



Philips Head  
Screwdriver

# How-To-Guide

## Base Cabinets

### Instructions:

*\*Do not fully tighten cam lock screws until step 5\**

**1**



Lay the face frame face down and apply glue (optional) to the face frame dado and insert the cabinet sides into the dado.

**2**



Glue (optional) and insert the cabinet bottom into the side panel dados.

**3**



Screw the drawer glide brackets into the cabinet back.

**4**



Slide the back of the cabinet into the side panel grooves and clamp the left and right-side panels together.

**5**



Attach the back panel of the cabinet to the sides and bottom using the supplied pocket screws in the pre drilled pocket holes.

**6**



Secure the toe kick between bottom left and right panels with cam locks.

**7**



Carefully turn the cabinet over to fully tighten all cam screws from bottom to top.

**8**



Attach the drawer slides to the cabinet face frame and rear brackets.

Tools and  
Materials  
Needed for  
Assembly



Drill



Hammer  
and Mallet



Wood Glue  
(optional)



Bar Clamp



Cutter



Pencil



Philips Head  
Screwdriver

# How-To-Guide

## Base Cabinets

### Instructions:

9



Add glue (optional) to each dovetail dado on all drawer box pieces.

10



Attach the left and right drawer box sides to the drawer head and tap the dovetails into place using the mallet (Note: The drawer box front is pre-attached to the drawer head).

11



Insert the bottom of the drawer into the drawer box dados, then attach the back of the drawer box and tap the dovetails into place using the mallet.

12



Attach the drawer slide clips to the front underside. Insert the drawer box into the cabinet.

13



Glue (optional) the corner brackets and screw to all four corners of the cabinet.

14



Attach the hinges to the door and then attach the door to the face frame.



Assembled Base  
Cabinet