

Tools and
Materials
Needed for
Assembly



Drill



Hammer
and Mallet



Wood Glue
(optional)



Bar Clamp



Cutter



Pencil



Philips Head
Screwdriver

How-To-Guide

Wall Cabinets

Instructions:

1



Lay the face frame face down and apply glue (optional) to the face frame dado. Insert the cabinet sides into the dado.

****Do not fully tighten cam lock screws until step 6****

2



Glue (optional) and insert the cabinet bottom and top panels into the side panel dados.

3



Apply glue (optional) to the cabinet back dados and insert the cabinet back.

4



Attach the back of the cabinet to the sides, top, and bottom panels using the supplied pocket screws in the predrilled pocket holes.

5



Carefully turn the cabinet over to fully tighten all cam screws from bottom to top.

6



Insert shelf clips into the holes on the sides and insert the shelves.

****(Image will be replaced)***

7



Attach the hinges to the door panel and then attach the door to the face frame.



Assembled Wall
Cabinet